



PARTS LIST

BRUSHCUTTERS

BC2611LE

BC2611WE

NOTE:

1. Use HUSQVARNA ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. HUSQVARNA ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

Fig.1 CUTTER GROUP LE	2
Fig.2 CUTTER GROUP WE	4
Fig.3 ENGINE GROUP	6
Fig.4 CARBURETOR	8

APPLICABLE SERIAL NUMBERS:

71000101 and up

November 2012

Fig.1 CUTTER GROUP




Fig.1 CUTTER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE
1	T3403-11301	PIPE COMP.	1	1500x24xT1.5	60	521 85 16-01	• SWITCH	1	
2	3520-12213	SHAFT, spline ϕ 7x7teeth	1	1470x7	61	521 51 77-01	• SCREW	4	
4	574 71 65-01	GEARCASE ASSY	1		62	529 25 71-01	• CABLE COMP.	1	
5	574 26 75-01	• GEARCASE	1		63	529 25 61-01	• CORD COMP.	2	
6	06000-00626	• BEARING	1		64	521 80 55-01	• TUBE	1	
7	06000-06000	• BEARING	1		65	529 25 94-01	• BAND	2	
8	3565-13130	• SEAL	1		66	504 11 43-01	• BOLT	2	
9	04065-02612	• SNAPRING	1		67	510 91 11-01	• NUT	2	
10	T3002-13210	• SHAFT	1		73	848BU36914	TAP HEAD COMP.	1	
11	T3317-13220	• GEAR	1		74	848BU369M4	• CASE	1	
12	6440-13242	• HOLDER (A)	1		75	T3189-15191	• EYELET	2	
13	6019-13250	• HOLDER (B)	1		76	T3189-15132	• COVER	1	
14	T3002-13260	• NUT	1		77	T3189-15142	• CORD HOLDER	1	
15	848JC061D0	• PINION	1		78	T3189-15160	• SPRING	1	
16	06000-00609	• BEARING	1		79	848BU369S0	• CORD	1	
17	06001-00609	• BEARING	1		80	8488U00210	TOOL SET	1	
18	T3300-13330	• SNAPRING	1		81	09007-00425	• WRENCH	1	
19	04065-02412	• RING	1		82	8488U10050	• SOCKET	1	
20	T4950-53040	• BOLT TORX	1	M5x30	83	1030-91340	• DRIVER	1	
21	T4950-60800	• BOLT TORX	1	M6x8					
22	01641-20608	• WASHER	1						
23	T4950-51200	• BOLT TORX	1	M5x12					
24	T3300-17202	HANGER COMP.	1						
25	8488052000	SCREW	1						
26	848JPN90R0	PLATE NAME	1						
27	8488X10020	PLATE CAUTION	1						
28	848JL066A5	GUARD	1						
29	848JL06635	GUARD ASSY	1						
30	848JL066B2	• BLADE	1						
31	4820-72150	• BOLT TORX	1	M4x16					
32	3238-13150	• NUT	1	M4					
33	3550-14170	SPACER	1						
34	848JC266C0	BRACKET	1						
35	T4950-63040	BOLT TORX	2	M6x30					
41	3540-13283	COVER (NUT)	1						
42	6242-92110	GOGGLE	1						
43	848J823610	STRAP ASSY	1						
45	T3110-14000	HANDLE ASSY	1						
47	0263-90530	• SCREW	4						
52	574 39 03-02	GRIP ASSY	1						
53	576 47 52-02	• GRIP, HALF SET	1						
55	529 25 88-01	• LEVER, THROTTLE	1						
56	529 25 96-01	• SPRING, THROTTLE	1						
57a	8488RD0601	• LEVER, SAFETY	1	(~#11299999)					
57b	578 77 80-01	• LEVER, SAFETY	1	(#20400101~)					
58	511 59 18-01	• SPRING	1						
59	529 25 92-01	• LEVER, JOINT	1						

Fig.2 CUTTER GROUP




Fig.2 CUTTER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE
1	T3403-11301	PIPE COMP.	1	1500x24xT1.5	58	T3189-15132	• COVER	1	
2	3520-12213	SHAFT, spline ø7x7teeth	1	1470x7	59	T3189-15142	• CORD HOLDER	1	
4	574 71 65-01	GEARCASE ASSY	1		60	T3189-15160	• SPRING	1	
5	574 26 75-01	• GEARCASE	1		61	848BU369S0	• CORD	1	
6	06000-00626	• BEARING	1		62	8488U00210	TOOL SET	1	
7	06000-06000	• BEARING	1		63	09007-00425	• WRENCH	1	
8	3565-13130	• SEAL	1		64	8488U10050	• SOCKET	1	
9	04065-02612	• SNAPRING	1		65	1030-91340	• DRIVER	1	
10	T3002-13210	• SHAFT	1		68	848JJ83220	HANDLE (L) ASSY	1	
11	T3317-13220	• GEAR	1		69	848JPN3210	HANDLE (R) ASSY	1	
12	6440-13242	• HOLDER (A)	1		71	8488R40560	• GRIP ASSY	1	
13	6019-13250	• HOLDER (B)	1		72	576 04 53-01	•• HANDLE, HALF SET	1	
14	T3002-13260	• NUT	1		74	848JL033C3	•• LEVER	1	
15	848JC061D0	• PINION	1		75	848JL033D2	•• SPRING	1	
16	06000-00609	• BEARING	1		76	848JL033E3	•• LEVER-S	1	
17	06001-00609	• BEARING	1		77	T4506-52110	•• SWITCH	1	
18	T3300-13330	• SNAPRING	1		78	8488241600	•• SCREW	4	
19	04065-02412	• RING	1		79	T4960-53010	•• SCREW TORX	1	
20	T4950-53040	• BOLT TORX	1	M5x30	80	3320-15310	•• NUT	1	
21	T4950-60800	• BOLT TORX	1	M6x8	81	8488P00320	•• CABLE COMP.	1	
22	01641-20608	• WASHER	1		82	8488M10750	•• CORD COMP.	2	
23	T4950-51200	• BOLT TORX	1	M5x12	83	T3004-14810	•• TUBE	1	
24	T3300-17202	HANGER COMP.	1						
25	8488052000	SCREW	1						
26	848JPN90R0	PLATE NAME	1						
27	8488X10020	PLATE CAUTION	1						
28	848JL066A5	GUARD	1						
29	848JL06635	GUARD ASSY	1						
30	848JL066B2	• BLADE	1						
31	4820-72150	• BOLT TORX	1	M4x16					
32	3238-13150	• NUT	1	M4					
33	3550-14170	SPACER	1						
34	848JC266C0	BRACKET	1						
35	T4950-63040	BOLT TORX	2	M6x30					
41	3540-13283	COVER (NUT)	1						
42	6242-92110	GOGGLE	1						
43	848J823610	STRAP ASSY	1						
46	848JG03230	BRACKET ASSY	1						
47	848JG032B1	• BRACKET	1						
48	3541-14182	• CAP-L	1						
49	848JL132K1	• BRACKET-UP	1						
50	4820-13180	• BOLT	4						
51	T4950-52540	• BOLT	2						
52	T3300-14191	PLATE	2						
53	848B8138A1	PROTECTOR	1						
54	3540-93120	BAND	1						
55	848BU36914	TAP HEAD COMP.	1						
56	848BU369M4	• CASE	1						
57	T3189-15191	• EYELET	2						

Fig.3 ENGINE GROUP




Fig.3 ENGINE GROUP

Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE
1	T1800-12111	CYLINDER	1		55	T1600-72210	CLAMP	1	
2	515 40 88-01	GASKET, base	1		56	T1700-32112	COVER, engine	1	
3	1850-12130	BOLT	2	M5x22	57	T1700-32162	SCREW	1	M5x16
4	3699-90332	SPARK PLUG (NGK)	1	BPMR7A	58	0263-90514	SCREW	1	M5x14
5	5881-21102	CRANKCASE COMP.	1		59	848EA05110	SHOE COMP.	1	
6	2629-21130	• PIN	3		60	T1700-51220	• SPRING	1	
7	5500-21141	GASKET	1		61	1140-51250	SCREW	2	
8	T1802-221240	BEARING	2		62	1140-51230	WASHER	2	
9	2169-21210	SEAL	1		63	T1600-51240	WASHER	2	
10	1850-21220	SEAL	1		64	T1700-71110	ROTOR	1	
11	04065-02812	SNAP RING	1	φ 28	65	T1700-71201	COIL ASSY	1	
12	01252-30530	BOLT	4	M5x30	66	5500-72110	• CAP	1	
13	5500-22110	GUARD	1		67	T1700-71220	• CORD	1	
14	0263-90514	SCREW	1	M5x14	68	2616-71320	• CAP	1	
15	5500-42001	CRANKSHAFT COMP.	1		69	5500-72130	• GROMMET	1	
16	5910-41110	PISTON	1	φ 34	70	5500-72120	• SPRING	1	
17	8488C34200	RING	2	φ 34	71	3310-72150	BOLT	2	M4x20
18	1600-41310	PIN	1		72	T1700-71260	SPACER	2	
19	1260-41320	RING	2		73	T1700-73200	CORD COMP.	1	
20	5500-41410	BEARING	1		74	1650-43230	NUT	1	M8
21	1101-41340	WASHER	2		75	1000-43240	KEY	1	
22	T1700-15110	MUFFLER	1		76	T1700-75100	RECOIL ASSY	1	
23	01252-30550	BOLT	2	M5x50	77	5500-75110	• CASE COMP.	1	
24	T1600-15210	GASKET	1		78	1850-75120	• REEL	1	
25	5500-15221	PLATE	1		79	1850-75130	• SPRING	1	
26	0263-90416	SCREW	1	M4x16	80	1850-75151	• SCREW	1	
27	T1700-13160	INSULATOR	1		81	T1600-75160	• ROPE	1	
28	5500-13122	GASKET, insulator	1		82	T1600-75310	• KNOB	1	
29	5500-13131	GASKET, cab	1		83	T1600-75321	• COLLER	1	
30	0263-90520	SCREW	2	M5x20	84	T1600-75330	• SPRING	1	
31	848EFG8101	CARBURETOR ASSY	1	WYJ-290	85	T1600-75210	• WASHER	1	
32	T1825-82510	PLATE	1		86	1850-75201	PULLY, ASSY	1	
33	T1825-82521	GASKET	1		87	1850-75221	• RATCHET	1	
34	T1700-82100	BODY ASSY	1		88	1850-75230	• SPRING	1	
35	1970-82190	• SLEEVE	2		89	T1700-32162	SCREW	4	M5x16
36	T1700-82130	• PLATE, choke	1		90	T1800-85001	TANK ASSY	1	
37	T1700-82140	• LEVER, choke	1		91	5607-85201	• CAP ASSY	1	
38	2630-33610	• SCREW	1		92	5601-85300	• • HOLDER ASSY	1	
39	5500-82171	ELEMENT	1		93	5500-85220	• • PACKING	1	
40	T1701-82200	COVER, ASSY	1		94	5601-85260	• • FILTER	1	
41	5500-82221	• KNOB	1		95	4820-85260	• • STOPPER	1	
42	0263-90560	SCREW	2	M5x60	96	5500-85300	• PIPE COMP	1	
43	T1702-31101	HOUSING ASSY	1		97	5500-85400	• FILTER ASSY	1	
45	T1701-31151	• BEARING	1		98	1260-85460	• CLIP	1	
46	848F3051A1	• DRUM	1		99	5910-85510	SCREW	1	M5x16
47	04064-01210	• RING	1	φ 12	100	5500-85510	SCREW	2	M5x16
48	04065-02812	• RING	1	φ 28	101	T1807-75411	LABEL, recoil	1	
49	T1700-31212	BRACKET (A)	1		102	T1600-31131	LABEL	1	
50	T1700-31221	BRACKET (B)	1		103	4500-81910	COVER	1	
51	T1700-31232	CUSHION	1		104	1950-86120	CLIP	1	
52	01252-30522	BOLT	2	M5x22	105	848EGY85Z0	GUARD	1	
53	01252-30510	BOLT	1	M5x10	106	3350-21320	BOLT	2	M5x30
54	0263-90520	SCREW	2	M5x20					

Fig.4 CARBURETOR WYJ-290B




Fig.4 CARBURETOR WYJ-290B

Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE
1	848EFG8101	CARBURETOR ASSY	1	WYJ-290B					
2	1794-81450	• BODY ASSY	1						
3	3306-81380	• • SCREEN	1						
4	3356-81310	• • VALVE, inlet	1						
5	1794-81270	• • SPRING	1						
6	1850-81220	• • SCREW	1						
7	3310-81250	• • PIN	1						
8	3310-81230	• • LEVER	1						
9	1850-81490	• BODY	1						
10	1850-81520	• COVER, pump	1						
11	1751-81510	• PUMP, primer	1						
12	848HE081K0	• DIAPHRAGM	1						
13	1850-81470	• GASKET	1						
14	1065-81420	• DIAPHRAGM, pump	1						
15	4810-81410	• GASKET	1						
16	T1513-81250	• JET	1	#39					
17	1751-81240	• O-RING	1						
18	1751-81130	• RING	1						
19	1881-81140	• SWIVEL	1						
20	5500-81160	• WASHER	1						
21	T1700-81150	• VALVE ASSY	1						
22	1752-81110	• SCREW	2						
23	5500-81120	• BRACKET	1						
24	1751-81180	• NUT, adjuster	1						
25	1918-81170	• SCREW, adjuster	1						
26	1881-81130	• RING	1						
27	1850-81530	• SCREW	4						